



**iQuant™ ssDNA Assay Kit**  
**(1 – 200 ng)**  
**Catalog Number: N014, N015**

**Table 1. Kit Components and Storage**

Material	Amount	Concentration	Storage	Stability
<b>iQuant™ ssDNA Assay Kit (Cat. No. N014)</b>				The product is stable for at least 6 months when stored as directed.
iQuant™ ssDNA Reagent (Component A)	200 µL	200X in DMSO	2-8 °C Protect from light	
iQuant™ ssDNA Buffer (Component B)	50 mL	1X		
ssDNA Standard #1 (Component C)	200 µL	0 ng/µL in TE buffer		
ssDNA Standard #2 (Component D)	200 µL	20 ng/µL in TE buffer		
<b>iQuant™ ssDNA Assay Kit (Cat. No. N015)</b>				
iQuant™ ssDNA Reagent (Component A)	1 mL	200X in DMSO	2-8 °C Protect from light	
iQuant™ ssDNA Buffer (Component B)	200 mL	1X		
ssDNA Standard #1 (Component C)	1 mL	0 ng/µL in TE buffer		
ssDNA Standard #2 (Component D)	1 mL	20 ng/µL in TE buffer		

**Approximate fluorescence excitation/emission maxima, in nm: 500/530, bound to DNA.**

**Product Description**

The iQuant™ ssDNA Assay Kit provides an easy and accurate quantitation for ssDNA or oligonucleotides. The kit is not selective for ssDNA over dsDNA or RNA, but it will not detect contaminating protein or nucleotides. The assay kit is highly reliable in detecting ssDNA ranging from 1 to 200 ng, and offers advantages in stability, linear dynamic range, and sensitivity over other traditional of DNA quantitation. The kit contains concentrated assay reagent, dilution buffer, and pre-diluted ssDNA standards. The assay is performed at room temperature. Simply dilute the reagent using the buffer provided, add your sample (any volume between 1 µl and 50 µl is acceptable), and read the fluorescence using fluorescence plate reader or Fluorometer such as Qubit® or Quantus™ Fluorometer. The kit is well tolerated to common contaminants such as proteins, salts, solvents and detergents.

**Handling and Disposal**

There is no safety data available for iQuant™ ssDNA reagent. Treat the iQuant™ ssDNA reagent with the safety precautions as other potentially harmful reagents and to dispose of the reagent in accordance with local regulations. Centrifuge the iQuant™ ssDNA reagent and the ssDNA standards before opening vials to minimize loss on the cap. Use properly calibrated pipettes for best accuracy.

## General Protocol

### 1. Measure ssDNA samples using a Fluorescence Microplate Reader


**(Note: For simplicity, the following protocol is written using 10  $\mu$ L of ssDNA sample volume. In practice, the volume of ssDNA sample could be ranging from 1  $\mu$ L to 50  $\mu$ L depending on the concentration of ssDNA sample, then adjust the volume of iQuant™ working solution to 200  $\mu$ L.)**

- 1.1 Warm up the iQuant™ ssDNA Assay Kit to room temperature. Check the iQuant™ ssDNA reagent for any precipitation. If precipitation is seen, warm up the vial in a water bath and vortex until dissolved.
- 1.2 Prepare the iQuant™ working solution by diluting the iQuant™ ssDNA reagent 1:200 in 1X iQuant™ ssDNA Buffer **IMMEDIATELY** before use. Use a clean plastic tube each time you make iQuant™ working solution. For example, to measure 8 samples in duplicate, add 20  $\mu$ L of iQuant™ ssDNA reagent to 4 mL of 1X iQuant™ ssDNA Buffer. Mix well and use immediately.
- 1.3 Add 190  $\mu$ L of the iQuant™ working solution to each well of a black 96-well microplate. Black plates such as Greiner or Corning black 96-well plates are recommended to minimize fluorescence bleed-through from other well.
- 1.4 Prepare a series of ssDNA standard dilutes from ssDNA Standard #2 (Component D) or your known ssDNA sample.
- 1.5 Add 10  $\mu$ L of each ssDNA standard dilutes and the unknown ssDNA samples in duplicate or triplicates into separated wells and mix well by pipetting up and down.
- 1.6 Incubate the microplate at room temperature for 2 minutes in the dark.
- 1.7 Measure the fluorescence using a microplate reader with 485 nm excitation and 530 nm emission, with the appropriate cut-off.
- 1.8 Generate a linear standard curve by plotting fluorescence versus DNA concentration of the DNA standards. Use the standard curve and the fluorescence of the unknown DNA samples to determine the unknown DNA concentration.


### 2. Measure ssDNA samples using the Qubit® Fluorometer from Invitrogen

**(Note: For simplicity, the following protocol is written using 10  $\mu$ L of ssDNA sample volume. In practice, the volume of ssDNA sample could be ranging from 1  $\mu$ L to 50  $\mu$ L depending on the concentration of ssDNA sample, then adjust the volume of iQuant™ working solution to 200  $\mu$ L.)**


- 2.1. Warm up the iQuant™ ssDNA Assay Kit to room temperature. Check the iQuant™ ssDNA reagent for any precipitation. If precipitation is seen, warm up the vial in a water bath and vortex until dissolved.
- 2.2. Prepare the iQuant™ working solution by diluting the iQuant™ ssDNA reagent 1:200 in 1X iQuant™ ssDNA Buffer **IMMEDIATELY** before use. Use a clean plastic tube each time you make iQuant™ working solution. For example, to measure 8 samples in duplicate, add 10  $\mu$ L of iQuant™ ssDNA reagent to 2 mL of 1X iQuant™ ssDNA Buffer. Mix well and use immediately.
- 2.3. Add 190  $\mu$ L of the iQuant™ working solution to each assay tube. (**Note:** Use only thin-wall, clear 0.5 mL PCR tubes. Axygen PCR-05-C tubes (VWR, Cat No. 1011-830)).
- 2.4. Add 10  $\mu$ L of ssDNA standard #1 (Component C), ssDNA standard #2 (Component D), and the unknown ssDNA samples to the appropriate tubes and mix by vortexing 2-3 seconds, and label the lids of each DNA standard tube and unknown sample tubes correctly.
- 2.5. Incubate all tubes at room temperature for 2 minutes in the dark.
- 2.6. Measure the fluorescence on the Qubit® fluorometer using the **ssDNA** program, according to the manufacture's recommendation.



**Figure 1.** Excitation (blue) and emission spectra (red) of iQuant™ ssDNA reagent in the presence of ssDNA.



**Figure 2.** The quantitation of ssDNA with iQuant™ ssDNA Assay Kit using fluorescence plate reader.



**Figure 3.** The quantitation of ssDNA with iQuant™ ssDNA Assay Kit using Qubit® Fluorometer.

### Considerations for Data Analysis

It is more prefer to use a ssDNA standard similar to the unknown samples (i.e. similar in size). We found using the iQuant™ ssDNA reagent most ssDNA yield similar results. If the fluorescence of an unknown sample is higher than ssDNA standard #2 (Component D), further dilute the sample and add 10 μL of diluted sample to perform the assay.


## Appendix

**Table 2. Effect of Contaminants in the iQuant™ ssDNA Assay**

Contaminant	Final Concentration in Assay	Concentration in 10 $\mu$ L Sample	Result
<b>Proteins</b>			
Bovine Serum Albumin	50 $\mu$ g/mL	1 mg/mL	OK
<b>Salts</b>			
Sodium Chloride	2.5 mM	50 mM	OK
Magnesium Chloride	0.1 mM	2 mM	OK
Sodium Acetate	1 mM	20 mM	OK
Ammonium Acetate	1 mM	20 mM	OK
<b>Organic Solvents</b>			
Ethanol	0.5%	10%	OK
Chloroform	0.1%	2%	OK
Phenol	0.01%	0.2%	OK
<b>Detergents</b>			
Triton X-100	0.005%	0.1%	OK

## Related Products

Cat. No.	Product Name	Unit Size
<b>N010</b>	iQuant™ dsDNA HS Assay Kit	200 assays
<b>N011</b>	iQuant™ dsDNA HS Assay Kit	1000 assays
<b>N012</b>	iQuant™ dsDNA BR Assay Kit	200 assays
<b>N013</b>	iQuant™ dsDNA BR Assay Kit	1000 assays



**Figure 4.** iQuant™ ssDNA Assay workflow